



Presents:

 **Temper-Sure™**

Access Control Thermal Camera



Access Control Thermal Camera for personnel screening

As we reopen workplaces throughout the country, social distancing and mask wearing are important measures we can all take to help minimize the risk of infection. Screening for correct mask wearing compliance, and also for raised temperatures may help to create a safer work environment, and may assist with getting businesses back to work.

The Temper-Sure Access Control Thermal Camera is a high quality thermal camera for scanning personnel and visitors, detecting mask compliance and raised temperatures.

Building access can be screened without human interaction, thereby potentially minimizing the risk of personnel infection.



Introducing the Temper-Sure™ Access Control Thermal Camera for personnel screening



FEATURES

- Non-contact, automatic temperature taking while recognizing faces, efficiently and effectively
- Temperature range: 86-113° F (30-45° C) ±0.3° accuracy
- Detects people who are not wearing a protective mask, if required
- Push alarm messaging

How It Works

OUT OF THE BOX



RIGHT OUT OF THE BOX, the Temper-Sure thermal camera requires very little setup and no professional installation to operate as a stand-alone unit. It can be easily programmed to monitor:

- Body Temp. ID
- Facial Recognition
- Mask Detection

Comes with wall mount and pipe mount. Or, the camera can be easily mounted to desktop and/or full height tripods.



Stand Options



Standard Camera Column:

Column height: 120cm

Comes with 2 USB ports

Base with adjusting screw

Cool blue light strip design



Desktop-style base

Base thickness: 3.8 cm


Comes with 2 USB ports

Base with adjusting screw

Cool blue light strip design

How It Works

CONNECTIVITY




Your thermal cameras may operate as individual stand-alone units right out of the box, or as numerous units connected in custom fashion. They can work 100% independent of a computer device or they may be easily integrated into your existing access/security network via the included cable bundle.

Camera settings can be easily controlled from a web browser pointed to an secure Temper-Sure camera IP/web address.

How It Works

BASIC INSTALLATION vs ADVANCED OPTIONS

BASIC - SELF SETUP
(anyone can do it!)




- Body Temp. ID
- Facial Recognition
- Mask Detection

USING YOUR SECURITY TEAM



With proper internal support, Temper-Sure can securely connect with your existing access and/or security system. Camera data can be compiled in databases for numerous statistical purposes.

**NO IN HOUSE TECH SUPPORT?
USE A TEMPER-SURE APPROVED CONTRACTOR**



Temper-Sure has forged strong relationships with hundreds of high-tech installation experts all across the U.S. Choosing this option gives you instant access to world-class, customized installation.

How It Works

ACCESS CONTROL CAMERA (face recognition/temperature indicator)

